

Order Template

M-PRO **aaaa - b - c - d - e - f - g - h**

Ordering Code Example	M-PRO	2000	3	B	3	0	0	0	B
Model - 27/59DT, 27/59IT, 59NDT, 59NIT, 47DT, 47IT, 37, 50/67, 51/67, 50N/67N, 51N/67N, 50G/67G, 51G/67G, 46/50, 46/51, 50BF, I2t, 46BC, 81HBL2, 48, 51LR, 66, 60VTS, 60CTS, THD, 74TCS – 3VT + 4CT									
Aux Supply & External Input Rating - 80 to 300 V _{dc} / 80 to 250 V _{ac} , External Input – 110/125 V _{dc}									
Enclosure, Number of inputs, outputs & LEDs - E8 case, 14 External inputs, 14 Relay outputs & 14 LED's									
Communication Ports - one Ethernet port (100BASE-T, RJ45)									
Conformal Coating - Not Conformal Coated									
Custom Firmware Request - Latest version									
Custom Hardware Request - No special build instructions									
Configuration ID Version – Internal Use									

Standard Functions & Features:

- 1A (or) 5A CT secondary input is site selectable
- Disturbance recorder, fault recorder, metering, Prologic, trip circuit supervision
- Front USB port and rear serial RS485 port and horizontal flush panel mounting chassis
- Modbus (or) IEC103 (or) DNP3.0 are supported over RS485 port and DNP3.0 and IEC 61850 are supported over Ethernet
- PPM, IRIG-B (or) SNTP for time sync

Manuals:

The latest version of the manuals can be downloaded from our website:

<http://www.erlphase.com/support.php?ID=documents>. If you do wish to purchase a hard copy manual, you may order that using the part number below.

<Part # 119635> M-PRO 2000 User Manual

ERLPhase Power Technologies

Tel: +1 204-477-0591

Toll Free: 1-833-502-2160 (US & Canada)

Email: info@erlphase.com



The specifications and product information contained in this document are subject to change without notice. In case of inconsistencies between documents, the version at www.erlphase.com will be considered correct. (D05366R01)