

B-PRO 4000 Bus Protection Relay (3-Phase)

Order Template

In order to specify and order an ERLPhase B-PRO 4000 relay properly configured for the application, order string options must be selected as indicated below:

B-PRO 4000 a - b - ccc - d - e - f - gg - h - i - j - k

a: Model:

- 3: 3U chassis with 9 digital inputs, 14 digital outputs, 18 CT inputs, 3 PT inputs

b: Secondary Input Current:

- 1: 1 Amp
- 5: 5 Amp

ccc: External Input Rating:

- 048: 48/125/250 Vdc set to 48 Vdc
- 125: 48/125/250 Vdc set to 125 Vdc
- 250: 48/125/250 Vdc set to 250 Vdc

d: Internal Modem:

- 0: No internal modem (default)

Selection 1 is available only if “no redundancy option 0” is chosen in “e.”

- 1: Factory installed modem

e: LAN Redundancy Selection

Network port redundancy on rear Ethernet port 119 is now available as an option at an additional cost. This option allows you to select whether you need redundancy, and if so, the kind of redundancy needed.

- 0: No redundancy (default)
- 1: RSTP Redundancy on Ethernet ports 119 and 124 (Internal Modem and Conformal coating are not available if selected)
- 2: PRP Redundancy on Ethernet ports 119 and 124 (Internal Modem and Conformal coating are not available if selected)
- 3: HSR Redundancy on Ethernet ports 119 and 124 (Internal Modem and Conformal coating are not available if selected)

f: LAN Media Selection:

Selection 0, 1 and 2 are available if “no redundancy option 0” is selected in “e.”

- 0: Cu - Op => port 119 = 100BASE-T (RJ45), port 120 = 100BASE-FX (multimode, 1300 nm, ST)
- 1: Op - Op => port 119 = port 120 = 100BASE-FX (multimode, 1300 nm, ST)
- 2: Cu - Cu => port 119 = port 120 = 100BASE-T (RJ45)

Selections 3 and 4 are available only if a redundancy option is selected in “e.”

- 3: Cu - Op => port 119 = port 124 = 100BASE-T (RJ45), port 120 = 100BASE-FX (multimode, 1300 nm, LC)
- 4: Op - Op => port 119 = port 124 = 100BASE-FX (multimode, 1300 nm, LC), port 120 = 100BASE-FX (multimode, 1300 nm, LC)

gg: Operating Frequency:

- 50: 50 Hertz
- 60: 60 Hertz

h: Conformal coating:

- 0: Not conformal coated (default)
- 1: Conformal coated



i: Custom Firmware Request:

- 0: Latest version (default)
- 1: Custom version (please specify firmware version number)

j: Custom Hardware Request:

- 0: No special build instructions (default)
- 1: Special build instructions (please provide special instructions)

k: This is a reserved character on the order string for internal purposes only.

Example: B-PRO 4000 (3-5-125-0-0-1-60-0-0-0-A)

This part number specifies a B-PRO 4000 relay in 3U chassis with 5 Amp secondary input current, 125 Vdc rated external inputs, no modem card, without network redundancy option, with both LAN ports to be used for optical communications, suitable for operation on 60 Hertz system, without conformal coating and with latest software version and standard hardware build.

Manuals:

In our ongoing efforts to run our business in an environmentally sensitive way, the latest version of the manuals can also be downloaded from our website <http://www.erlphase.com/support.php?ID=documents>. If you do wish to purchase a hard copy manual, you may order that using the part number below.

<Part # 109246> B-PRO 4000 User Manual

The specifications and product information contained in this document are subject to change without notice. In case of inconsistencies between documents, the version at www.erlphase.com will be considered correct. (D02633R12)