

T-PRO 4000 Transformer Protection Relay

Order Template

In order to specify and order an ERLPhase T-PRO 4000 properly configured for the application, a part number must be constructed as indicated below:

T-PRO 4000 a - b - ccc - d - e - f - g - hh - i - j - k - l

a: Model:

- 3: 3U chassis with 9 digital inputs, 14 digital outputs, 15 CT inputs, 3 PT inputs
- 4: 4U chassis with 20 digital inputs, 21 digital outputs, 15 CT inputs, 3 PT inputs

b: Secondary Input Current:

- 1: 1 Amp
- 5: 5 Amp

ccc: External Input Rating:

- 048: 48/125/250 Vdc set to 48 Vdc
- 125: 48/125/250 Vdc set to 125 Vdc
- 250: 48/125/250 Vdc set to 250 Vdc (Not available if CE compliance is required)

d: Internal Modem:

- 0: No internal modem (default)

Selection 1 is available only if “no redundancy option 0 is chosen in “e.”

- 1: Factory installed modem

e: LAN Redundancy Selection

Network port redundancy on rear Ethernet port 119 is now available as an option at an additional cost. This option allows you to select whether you need redundancy, and if so, the kind of redundancy needed.

- 0: No redundancy (default)
- 1: RSTP Redundancy on Ethernet ports 119 and 124 (Internal Modem and Conformal coating are not available if selected)
- 2: PRP Redundancy on Ethernet ports 119 and 124 (Internal Modem and Conformal coating are not available if selected)
- 3: HSR Redundancy on Ethernet ports 119 and 124 (Internal Modem and Conformal coating are not available if selected)

f: LAN Media Selection:

Selection 0, 1 and 2 are available if “no redundancy option 0 is selected in “e.”

- 0: Cu - Op => port 119 = 100BASE-T (RJ45), port 120 = 100BASE-FX (multimode, 1300 nm, ST)
- 1: Op - Op => port 119 = port 120 = 100BASE-FX (multimode, 1300 nm, ST)
- 2: Cu - Cu => port 119 = port 120 = 100BASE-T (RJ45)

Selections 3 and 4 are available only if a redundancy option is selected in “e.”

- 3: Cu - Op => port 119 = port 124 = 100BASE-T (RJ45), port 120 = 100BASE-FX (multimode, 1300 nm, LC)
- 4: Op - Op => port 119 = port 124 = 100BASE-FX (multimode, 1300 nm, LC), port 120 = 100BASE-FX (multimode, 1300 nm, LC)

g: Temperature Inputs:

- 0: No temperature inputs
- 1: 2 temperature inputs

hh: Operating Frequency:

- 50: 50 Hertz
- 60: 60 Hertz

i: Conformal coating:

- 0: Not conformal coated (default)
- 1: Conformal coated

j: Custom Firmware Request

- 0: Latest version (default)
- 1: Custom version (please specify firmware version number)

j: Custom Hardware Request

- 0: No special build instructions (default)
- 1: Special build instructions (please specify special instructions)

l: This is a reserved character on the order string for internal purposes only.

Example: T-PRO 4000 (3-5-125-0-0-1-0-60-0-0-0-A)

This part number specifies a T-PRO 4000 relay in 3U chassis with 5A secondary input current, 125 Vdc rated external inputs, no modem card, without network redundancy option, without temperature inputs, with both LAN ports to be used for optical communications, suitable for operation on 60 Hertz system, without conformal coating and with latest software version and standard hardware build.

Manuals:

In our ongoing efforts to run our business in an environmentally sensitive way, we include manuals with the CD of all our products. The latest version of the manuals can also be downloaded from our website <http://www.erlphase.com/support.php?ID=documents>. If you do wish to purchase a hard copy manual, you may order that using the part number below.

<Part # 113919> T-PRO 4000 User Manual